

PAB

Mounting Band

○ PAB series fixed steel belt (Fixed size for round body cylinder, HX-13 auto switch)

	Step 1	Step 2	Step 3	Step 4
	<p>Put the magnetic switch in the steel belt.</p>	<p>Get around the steel belt and magnetic switch.</p>	<p>Insert the steel belt into the slot, adjust the release of the switch, tighten the screw on the steel belt.</p>	<p>After adjusting the position of magnetic switch, fixed steel belt</p>
	<p>PAB - S 2 0 Bore</p> <p>S: The Round Barrel Cylinder (stainless steel material) Applicable to bore: 06、08、10、12、16、20、25、32、40、50、63</p> <p>A: The Round Barrel Cylinder (alluminum alloy material) Applicable to bore: 16、20、25、32、40</p>			

Note: This steel belt cannot be used in EG series round cylinder

○ PAB-13 series mounting band (Universal for HX-13 auto switch)

	Step 1	Step 2	Step 3	Step 4
	<p>1. Loosen the screw on the steel belt first</p> <p>2. Make sure that three to four circle of thread at the bottom of the screw is still in the nut</p>	<p>1. Get the steel belt through the hole at the bottom of HX-13</p> <p>2. Put the screw head into the slot of the clip</p> <p>3. Get the steel belt around the cylinder as below picture, then tighten the steel belt</p> <p>4. Mark on the round hole of the nearest PIN of the belt</p>	<p>1. Loosen the steel belt</p> <p>2. Mark the hole as below picture, and cut the belt on the second hole away from the mark hole</p>	<p>1. Put the belt that's just been cut down into the slot hole of the steel belt</p> <p>2. Put the chuck PIN onto the mark hole</p> <p>3. Use the thumb to press down the steel belt along the chuck, bending the belt</p> <p>4. Assemble the switch and the cylinder as below picture, then adjust the position of magnet switch, lock the screw, then you could fix it.</p>
	<p>PAB-13: Suitable for Φ6 ~ Φ63</p>			