

How to Order?

Series No.	O.D. of Tube	Port Size	Thread Type
EC	04: 4mm	01: 1/8" 06: 3/4"	P: PT
EH	06: 6mm	02: 1/4" 08: 1"	G: G
ELF	08: 8mm	03: 3/8" 10: 1-1/4"	T: NPT
...	10: 10mm	04: 1/2"	
	12: 12mm		

Order example:

EC series metal fitting, for 4mm OD tube, PT1/8" port size, ERP code is : EC04-01

Note: If both sides with tube, then show the size accordingly, if the same be same, then only show one. For example, EH fitting, both for 6mm OD tube, ERP code is : EH-06

<p>EC</p>  <p>Model EC 04-01 EC 06-01 EC 08-01 EC 10-01 EC 12-01 EC 04-02 EC 06-02 EC 08-02 EC 10-02 EC 12-02 EC 14-02 EC 16-02 EC 04-03 EC 06-03 EC 08-03 EC 10-03 EC 12-03 EC 14-03 EC 16-03 EC 04-04 EC 06-04 EC 08-04 EC 10-04 EC 12-04 EC 14-04 EC 16-04</p>	<p>EH</p>  <p>Model EH-06 EH-08 EH-10 EH-12 EH 1/4 EH 5/16 EH 3/8 EH 1/2 EH 3/4</p>	<p>ELF</p>  <p>Model ELF 01 ELF 02 ELF 03 ELF 04</p>	<p>EL</p>  <p>Model EL01 EL02 EL03 EL04</p>	
<p>EFM</p>  <p>Model EFM1 01 EFM1 01-02 EFM1 02-01 EFM1 02 EFM1 02-03 EFM1 03-02 EFM1 03 EFM1 04</p>	<p>ELFM</p>  <p>Model ELFM 01 ELFM 01-02 ELFM 02-01 ELFM 02 ELFM 02-03 ELFM 03-01 ELFM 03-02 ELFM 03 ELFM 03-04 ELFM 04-03 ELFM 04</p>	<p>ECF</p>  <p>Model ECF 01 ECF 02-01 ECF 02 ECF 03-01 ECF 03-02 ECF 03 ECF 04-01 ECF 04-02 ECF 04-03 ECF-04 ECF 06-04 ECF 06</p>	<p>ECN</p>  <p>Model ECN 01 ECN 02-01 ECN 02 ECN 03-01 ECN 03-02 ECN 03 ECN 04-01 ECN 04-02 ECN 04-03 ECN 04 ECN 06-02 ECN 06-03 ECN 06-04 ECN 06 ECN 08-04 ECN 08-06 ECN 08 ECN 10</p>	
<p>ECH</p>  <p>Model ECH 6-01 ECH 8-01 ECH 10-01 ECH 12-01 ECH 6-02 ECH 8-02 ECH 10-02 ECH 12-02 ECH 14-02 ECH 16-02 ECH 6-03 ECH 8-03 ECH 10-03 ECH 12-03 ECH 14-03 ECH 16-03 ECH 6-04 ECH 8-04 ECH 10-04 ECH 12-04 ECH 14-04 ECH 16-04 ECH 19-04 ECH 8-06 ECH 10-06 ECH 12-06 ECH 14-06 ECH 16-06 ECH 19-06 ECH 25-06 ECH 10-08 ECH 12-08 ECH 14-08 ECH 16-08 ECH 19-08 ECH 1/8-01 ECH 3/16-01 ECH 1/4-01 ECH 5/16-01 ECH 3/8-01 ECH 1/2-01 ECH 1/8-02 ECH 3/16-02 ECH 1/4-02 ECH 5/16-02 ECH 3/8-02 ECH 1/2-02 ECH 5/8-02 ECH 3/4-02 ECH 1/4-03 ECH 5/16-03 ECH 3/8-03 ECH 1/2-03 ECH 5/8-03 ECH 3/4-03 ECH 1/4-04 ECH 5/16-04 ECH 3/8-04 ECH 1/2-04 ECH 5/8-04 ECH 3/4-04 ECH 1-04 ECH 3/8-06 ECH 1/2-06 ECH 5/8-06 ECH 3/4-06 ECH 1-06 ECH 1/2-08 ECH 3/4-08 ECH 1-08 ECH 1-1/4-08 ECH 1-1/2-08</p>		<p>ECHF</p>  <p>Model ECHF 6-01 ECHF 8-01 ECHF 10-01 ECHF 12-01 ECHF 6-02 ECHF 8-02 ECHF 10-02 ECHF 12-02 ECHF 14-02 ECHF 16-02 ECHF 6-03 ECHF 8-03 ECHF 10-03 ECHF 12-03 ECHF 14-03 ECHF 16-03 ECHF 6-04 ECHF 8-04 ECHF 10-04 ECHF 12-04 ECHF 14-04 ECHF 16-04 ECHF 19-04 ECHF 8-06 ECHF 10-06 ECHF 12-06 ECHF 14-06 ECHF 16-06 ECHF 19-06 ECHF 25-06 ECHF 10-08 ECHF 12-08 ECHF 14-08 ECHF 16-08 ECHF 19-08 ECHF 25-08 ECHF 33-08 ECHF 1/8-01 ECHF 3/16-01 ECHF 1/4-01 ECHF 5/16-01 ECHF 3/8-01 ECHF 1/2-01 ECHF 1/8-02 ECHF 3/16-02 ECHF 1/4-02 ECHF 5/16-02 ECHF 3/8-02 ECHF 1/2-02 ECHF 5/8-02 ECHF 3/4-02 ECHF 1/4-03 ECHF 5/16-03 ECHF 3/8-03 ECHF 1/2-03 ECHF 5/8-03 ECHF 3/4-03 ECHF 1/4-04 ECHF 5/16-04 ECHF 3/8-04 ECHF 1/2-04 ECHF 5/8-04 ECHF 3/4-06 ECHF 1-04 ECHF 3/8-06 ECHF 1/2-06 ECHF 5/8-06 ECHF 3/4-06 ECHF 1-06 ECHF 1-08 ECHF 3/4-08 ECHF 1-08 ECHF 1-1/4-08 ECHF 1-1/2-08</p>		<p>EHH</p>  <p>Model EHH 06 EHH 08 EHH 10 EHH 12 EHH 14 EHH 16 EHH 3/16 EHH 1/4 EHH 5/16 EHH 3/8 EHH 1/2 EHH 5/8 EHH 3/4</p>